

ADDRESS:

700 DOSTON AVE
FT. PIERCE, FL 34950

1. PRIME/PAINIT BOTH SIDES
2. INSTALL OVE EXISTING 6" T&G
3. INSTALL T-11 PLY WOOD
4. INSTALL 30# FELT
5. USE 1/4" Ring Shank Nails
6. WORK AREA: 8'x12'
7. FASTEN W/EN T-11 W/8d STAINLESS STEEL RINGS/SHANK NAILS @ 4" OC along sub

