



Client Value Agreement

Date: 10/16/2025

Addendum A

Client Name: City of Flagstaff

Client Number: 0035203

Contract Number: G250168

Contract Type: CVA Premium Plan

The following machines apply:

Premium Plan - Cost per Service (each)									
N/U	Model	Serial #	Equip #	PM1	PM2	PM3	PM4	PM5	Enrollment #
U	140 AWD	EB300955	S3198	\$1,467.47	\$1,607.22	\$2,447.34	\$4,278.18	\$4,801.28	
U	140 AWD	N9500709	S3199	\$1,583.13	\$1,669.00	\$2,828.97	\$3,997.66	\$4,393.55	
U	259D3	CW923489	S4031	\$728.07	\$987.84	\$1,395.71	\$1,689.94	N/A	
U	299D3	P3R01591	S3028	\$748.98	\$1,051.70	\$1,428.62	\$1,842.53	N/A	
U	420-07	H8T04107	S4032	\$1,117.78	\$1,269.54	\$1,739.11	\$2,127.65	\$2,516.69	
U	420-07	H8T04310	S3038	\$1,117.78	\$1,269.54	\$1,739.11	\$2,127.65	\$2,516.69	
U	627G	CEX00270	G8005	\$2,225.21	\$3,418.95	\$4,478.96	\$6,990.18	\$8,150.76	
U	730	3T400137	G8025	\$1,561.58	\$1,873.99	\$3,218.72	\$5,000.62	\$6,151.60	
U	826	F6X00136	G8029	\$1,771.05	\$2,580.68	\$3,179.07	\$4,795.73	\$6,145.86	
U	930M	F5K02785	S4030	\$1,201.77	\$1,282.15	\$1,489.88	\$2,591.06	\$3,258.82	
U	966H	A6D01586	G8-33	\$1,371.60	\$1,882.42	\$2,332.55	\$3,320.80	\$4,008.69	

Quote valid for 90 days from October 16th, 2025

Terms & Conditions:

The machines listed above are to be enrolled under the CVA with Empire created on 9/1/2024 and signed on 12/5/2024. Except with respect to these machines and the changes set forth by this addendum, the original agreement between the client and Empire shall remain in full force and effect.

Motor Grader: 140 AWD (EB3 and N95)

PM1-Service: Change engine oil and filter; SOS engine, transmission / differential, tandem, hydraulic, and front wheel oils; change fuel filters; check all fluid levels; change cab filters; change primary air filter; lubricate machine; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items, plus clean pre-cleaner; and change secondary air filter.

PM3-Service: Includes PM1 and PM2 service items, plus change transmission filter; clean suction screens; change hydraulic filters; change AWD filter; change engine fumes filter (if equipped); clean tandem breathers; change transmission breather; and obtain a level 1 coolant sample.

PM4-Service: Includes PM1, PM2, and PM3 service items, plus change transmission / differential oils; and change circle drive, tandem, and AWD gearbox oils.

PM5-Service: Includes PM1, PM2, PM3, and PM4 service items, plus change hydraulic oil.

Compact Track Loader: 259D3

PM1-Service: Change engine oil and filter; SOS engine, final drive and hydraulic oils; check all fluid levels; change primary air filter; change fuel filter; change cab filter; lubricate machine; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items plus change hydraulic breather; change final drive oil; clean pre-cleaner; and change secondary air filter.

PM3-Service: Includes PM1 and PM2 service items, plus change hydraulic filter; change engine fumes filter; and obtain a level 1 coolant sample.

PM4-Service: Includes PM1, PM2, and PM3 service items, plus change hydraulic oil.

Compact Track Loader: 299D3

PM1-Service: Change engine oil and filter; SOS engine, and hydraulic oil; check all fluid levels; lubricate machine; change cab filters; change primary air filter; change fuel filters; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items plus clean pre-cleaner; change secondary air filter; change final drive oil and change hydraulic tank breather.

PM3-Service: Includes PM1 and PM2 hour service items plus change hydraulic filter; change crankcase breather; and obtain coolant level 1 sample.

PM4-Service: Includes PM1, PM2, and PM3 service items, plus change hydraulic oil; and change DEF filter.

Backhoe Loader: 420-07

PM1-Service: Change engine oil and filter; SOS engine, transmission, differential / final drive, and hydraulic oils; check all fluid levels; change cab filters; change primary air filter; change fuel filter; lubricate machine; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items, plus clean pre-cleaner; change secondary air filter; and change transmission filter.

PM3-Service: Includes PM1 and PM2 service items, plus change front and rear differential and final drive oils; change hydraulic filter; and obtain level 1 coolant sample.

PM4-Service: Includes PM1, PM2, and PM3 service items, plus change DEF filter; and change transmission oil; clean suction screen; clean transmission breather.

PM5-Service: Includes PM1, PM2, PM3, and PM4 service items, plus change hydraulic oil and breather.

Auger: 627G

PM1-Service: Change engine oil and filters; SOS engine, transmission, differential / final drive, hydraulic, auger drive, and auger bearing oils; check all fluid levels; change cab filters; change primary air filters; change fuel filters; lubricate machine; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items, plus change transmission and hydraulic filters; clean pre-cleaners; change secondary air filters; and change auger filters.

PM3-Service: Includes PM1 and PM2 service items, plus change transmission oils and clean suction screens.

PM4-Service: Includes PM1, PM2, and PM3 service items, plus change differential / final drive, rear wheel bearing, auger bearing, and drive gear oils.

PM5-Service: Includes PM1, PM2, PM3, and PM4 service items, plus change hydraulic oils.

Articulated Truck: 730

PM1-Service: Change engine oil and filter; SOS engine, transmission / torque converter, transfer gear; differential, final drive, and hydraulic oils; check all fluid levels; change cab filters; change primary air filter; change fuel filters; lubricate machine; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items, plus change transmission filter; clean pre-cleaner; and change secondary air filter.

PM3-Service: Includes PM1 and PM2 service items, plus change transmission / transfer gear oils; clean suction screen; change hydraulic, transfer gear and axle oil cooler filters; change powertrain breathers; and obtain a level 1 coolant sample.

PM4-Service: Includes PM1, PM2, and PM3 service items, plus change differential and final drive oils; and change engine fumes filter.

PM5-Service: Includes PM1, PM2, PM3, and PM4 service items, plus change hydraulic oils.

Wheel Compactor: 826

PM1-Service: Change engine oil and filter; SOS engine, transmission / torque converter, differential, final drive and hydraulic oil; check all fluid levels; lubricate machine; change cab filters; change primary air filter; change fuel filters; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items plus change transmission and hydraulic filters; clean pre-cleaner; and change secondary air filter.

PM3-Service: Includes PM1 and PM2 hour service items, plus change transmission / torque converter oil and clean suction screen; and obtain coolant level 1 sample.

PM4-Service: Includes PM1, PM2 and PM3 service items, plus change differential and final drive oil.

PM5-Service: Includes PM1, PM2, PM3, and PM4 service items, plus change hydraulic oil.

Wheel Loader: 930M

PM1-Service: Change engine oil and filter; SOS engine, transmission / torque converter, differential, and hydraulic oils; check all fluid levels; change cab filters; change primary air filter; change fuel filters; lubricate machine; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items, plus clean pre-cleaner; and change secondary air filter.

PM3-Service: Includes PM1 and PM2 service items, plus change engine fumes filter; and obtain a level 1 coolant sample.

PM4-Service: Includes PM1, PM2, and PM3 service items, plus change transmission and hydraulic filters; change hydraulic tank breather; change differential and final drive oils; and change transmission / torque converter oils.

PM5-Service: Includes PM1, PM2, PM3, and PM4 service items, plus change hydraulic oil.

Wheel loader: 966H

PM1-Service: Change engine oil and filter; SOS engine, transmission / torque converter, differential / final drive, and hydraulic oils; check all fluid levels; change cab filters; change primary air filter; change fuel filters; lubricate machine; and perform visual and operational inspection.

PM2-Service: Includes PM1 service items, plus change transmission and hydraulic filters; clean pre-cleaner; and change secondary air filter.

PM3-Service: Includes PM1 and PM2 service items, plus change transmission / torque converter oil and clean suction screen.

PM4-Service: Includes PM1, PM2, and PM3 service items, plus change differential / final drive oil.

PM5-Service: Includes PM1, PM2, PM3, and PM4 service items, plus change hydraulic oil.

*****Action effective upon the date this document was signed as shown below.**



Client Value Agreement

CLIENT: CITY OF FLAGSTAFF

EMPIRE SOUTHWEST, LLC

By: _____

By: _____

Printed Name: _____

Printed Name: _____

Title: _____

Title: _____

Date: _____

Date: _____